


Figure 1-2. X11DPG-QT Motherboard Layout
(not drawn to scale)



Notes:



1. Components not documented are for internal testing only.

2. Intel VMD is supported by CPU1 SLOT9 and CPU2 SLOT10. After you've enabled VMD in the BIOS on a PCI-E slot of your choice, this PCI-E slot will be dedicated for VMD use only, and it will no longer support any PCI-E device. To re-activate this slot for PCI-E use, please disable VMD in the BIOS.